



CHESHIRE  
mouldings

Love the home you're in



**1200 - 1600MM  
FLAT ROOF  
PORCH CANOPY**



## FITTING INSTRUCTIONS

- 1) Measure and mark the Gallows Brackets position on the wall ensure you do not exceed the maximum span of 1600mm Note: Cheshire Mouldings Porch Canopies do allow for adjustability of the upright positions to less than 1600mm this takes into account any features around the door.
- 2) Place the back purlin at the preferred location above the door, measure and mark. (fig 1)
- 3) Assemble the Gallows Brackets using exterior grade wood glue. (fig 2)
- 4) Place the 15mm diameter dowels that are supplied into the pre-machined draw-bored tenons. (fig 3)
- 5) Place and secure the assembled Gallows Brackets to either side of the door frame in the marked positions on your wall and fix using 2 x 12mm Steel Bolts (not supplied). (fig 4)
- 6) Glue the cover caps to hide fixings. (fig 5)
- 7) Place the back purlin at the preferred location above the door, Secure with a minimum of 2 x 12mm steel bolts (not supplied) (fig 6)
- 8) Place the front purlin at the preferred location above the door using the rafters as a guide, Secure in place to the top of the brackets using the metal angled brackets and the 35mm screws that are provided. (fig 7 & 8)
- 9) Evenly space out the rafters over the frame at equal spacing, fix at the top and bottom using the 100mm screws provided (fig 9)

Maintenance - We recommend that you retreat your Porch Canopy and Accessories Kits annually by cleaning and repainting, staining or varnishing always follow the manufacturer's recommendations.

